PHANTOM SILVER SERIES PROFESSIONAL DIRECT DRIVE PRESSURE WASHERS

FEATURES

- » Honda Engines with low oil protection
- » Premium series Comet triplex pump with external unloader and bypass system
- » Adjustable pressure valve for cleaning convenience
- » Ultra lightweight aluminum frame with 1 1/4" tubing operator handle
- » 13" rugged pneumatic tires
- » Thermal safety relief protection
- » User friendly oil drain system
- » 50 mesh stainless steel inlet filter
- » 3/4" cold rolled steel axle
- » Dual anti-vibration rubber isolators



Units include 50' steel braided non-marking gray hose, 36" spray wand with molded grip and gun, 5 quick connect spray nozzles, and a high draw chemical injector. Hose reel kits and other options are available. See your PSI dealer for details.



PSI pressure washers feature Comet pumps for their unmatched quality and life.





PUMP FEATURES:

- » Forged brass manifold with lifetime warranty
- » Forged bronze connecting rods
- » High efficiency, stainless steel check valves
- » Abrasion proof, heat resistant, solid ceramic plungers
- » High quality oversized bearings
- » Increased fin depth for maximum heat dissipation



SPECIFICATIONS

MODEL	PSI	GPM	TIRES	ENGINE	PUMP	DIMENSIONS	UNIT WEIGHT
P-S2527HC	2500	2.5	10"	Honda GC160	BXD2527	36" x 21" x 26"	60 lbs.
P-S3027HC	2700	3.0	10"	Honda GX200	LWD3027	36" x 21" x 26"	75 lbs.
P-S3035HC	3500	3.0	13"	Honda GX270	ZWD3035	40" x 26" x 27"	110 lbs.
P-S4040HC	4000	4.0	13"	Honda GX390	ZWD4040	40" x 26" x 27"	119 lbs.



Pressure Systems Innovations

3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404

Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com

www.PressureSystemsInnovations.com