BANDIT[®] SKID SERIES BANDIT[®] SKID PRESSURE WASHERS

FEATURES

- » Honda engines with low oil protection
- » Premium Series industrial Comet triplex pump
- » External unloader and bypass system
- » Ultra lightweight aluminum skid
- » Easy access two piece aluminum belt guard
- » 3-groove "Bandit" belt for uniform tension and maximum power transfer
- » "EZ-line" belt tension assembly
- » Thermal relief safety protection
- » User friendly engine oil drain system
- » 50 mesh stainless steel inlet filter
- » Dual anti-vibration rubber isolators



Units include 50' steel braided non-marking gray hose, 36" spray wand with molded grip and gun, 5 quick connect spray nozzles, and a high draw chemical injector. Other kit options are available. See your PSI dealer for details.



PSI pressure washers feature Comet pumps for their unmatched quality and life.



- Forged brass manifold with lifetime warranty
- · Forged one-piece bronze alloy connecting rods
- » High efficiency, stainless steel check valves
- Abrasion proof, heat resistant, solid ceramic plungers
- Premium quality oversized bearings
- » Increased fin depth for maximum heat dissipation
- » Large crankcase capacity for improved cooling
- » Special PSI offering: 1 year "Bumper-to-Bumper" warranty on RW4040S pump – includes all normal wear items



B-K4040HC

SPECIFICATIONS

MODEL	PSI	GPM	ENGINE	PUMP	DIMENSIONS	UNIT WEIGHT
B-K4040HC	4000	4.0	Honda GX390	RW4040S	43" x 26" x 27"	144 lbs.
B-K5530HC	3000	5.5	Honda GX390	RW5530	43" x 26" x 27"	144 lbs.



Pressure Systems Innovations

3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404 Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com www.PressureSystemsInnovations.com