

# SMOKIN' BANDIT® SERIES HOT WATER PRESSURE WASHERS

## FEATURES

- » Honda GX390 Series engines with electric start and low oil protection
- » Industrial Comet triplex pump
- » Heavy duty powder coated frame
- » Ultra rugged corrosion resistant extruded aluminum base
- » 3-groove "Bandit" belt for uniform tension and maximum power transfer
- » "EZ-line" belt tension assembly
- » Easy access two piece aluminum belt guard
- » Stainless steel control panel with adjustable temperature control
- » Corrosion resistant stainless steel coil wrap
- » Over pressure and thermal relief valve protection
- » Easy pump and engine oil drains
- » Top-to-bottom schedule 80 coil for maximum temperature rise
- » 6-gallon poly diesel and gasoline fuel tanks



B-SH8030HC



POWERED by  
**HONDA**™

**PSI pressure washers feature Comet pumps for their unmatched quality and life.**



**PUMP FEATURES:**

- » Forged brass manifold with lifetime warranty
- » Forged one piece bronze alloy connecting rods
- » High efficiency, stainless steel check valves
- » Abrasion proof, heat resistant, solid ceramic plungers
- » Premium quality oversized tapered roller bearings
- » Increased fin depth for maximum heat dissipation
- » Large crankcase capacity for improved cooling
- » Special PSI offering: 1 year "Bumper-to-Bumper" warranty on entire pump – includes all normal wear items



## SPECIFICATIONS

MODEL	PSI	GPM	ENGINE	PUMP	DIMENSIONS	UNIT WEIGHT
B-SH4040HC	4000	4.0	Honda GX390	RW4040S	41" x 43" x 41"	400 lbs.
B-SH5530HC	3000	5.5	Honda GX390	RW5535S	41" x 43" x 41"	400 lbs.



Pressure Systems Innovations  
 3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404  
 Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com  
 www.PressureSystemsInnovations.com