ULTRA SMOKIN' BANDIT® SERIES HOT WATER PRESSURE WASHERS

FEATURES

- » Honda V-Twin GX Series or Kohler CH750 engines with low oil protection
- » Hi Flow Series industrial Comet triplex pump with lifetime warranty
- » Heavy duty powder coated frame
- » Ultra rugged corrosion resistant extruded aluminum base
- » 4-groove "Bandit" belt for uniform tension and maximum power transfer
- » "EZ-line" belt tension assembly
- » Easy access two piece aluminum belt guard
- » Stainless steel control panel with adjustable temperature control
- » Corrosion resistant stainless steel coil wrap
- » Over pressure and thermal relief valve protection
- » Easy pump and engine oil drains
- » Top-to-bottom schedule 80 coil for maximum temperature rise
- » Long run poly diesel and gasoline fuel tanks











PSI pressure washers feature Comet pumps for their unmatched quality and life.

BLOCK







- » Forged brass manifold with lifetime warranty
- » Forged one piece bronze alloy connecting rods
- » High efficiency, stainless steel check valves
- » Abrasion proof, heat resistant, solid ceramic plungers
- » Premium quality oversized tapered roller bearings
- » Increased fin depth for maximum heat dissipation
- » Large crankcase capacity for improved cooling
- » Special PSI offering: 1 year "Bumper-to-Bumper" warranty on entire pump – includes all normal wear items



SPECIFICATIONS

MODEL	PSI	GPM	ENGINE	PUMP	DIMENSIONS	UNIT WEIGHT
B-SH5535HC	3500	5.5	Honda GX630	RW5535S	45" x 32" x 47"	600 lbs.
B-SH8035HC	3500	8.0	Honda GX690	PS8010S	45" x 32" x 47"	600 lbs.
B-SH1035KC	3500	10.0	Kohler CH750	PS8010S	45" x 32" x 47"	600 lbs.
B-SH8040KC	4000	8.0	Kohler CH750	PS8010S	45" x 32" x 47"	600 lbs.



Pressure Systems Innovations

3750 Investment Lane » Suite 4 » West Palm Beach, FL 33404

Phone: 561.249.2830 » Fax: 561.249.2871 » sales@pressuresystemsinnovations.com